

INSTALLATION INSTRUCTIONS

- 1. EXCAVATE TANK HOLE WITH VERTICAL WALLS TO 1 FOOT LARGER THAN TANK ON ALL SIDES.
- 2. IF BOTTOM OF HOLE IS STONY, INSTALL 3" OF COMPACT SAND & LEVEL OUT WITH SCREED.
- 3. INSTALL TANK IN CENTER OF HOLE, KEEPING 1 FOOT VOID SPACE ON ALL SIDES
- 4. AS TANK IS FILLING WITH WATER, FILL IN VOID SPACE WITH COMPACT GRANULAR (SANDY) SOIL FREE OF LARGE CLUMPS OF CLAY. TANK MUST BE BACKFILLED BEFORE USE.
- 5. INSTALL REST OF SYSTEM, & AFFIX RISERS TO TANK /ADAPTORS WITH WATERPROOF ADHESIVE.
- 6. PERFORM WATERTIGHTNESS TEST IN FIELD AS REQUIRED BY LOCAL JURISDICTION.
- 7. UPON APPROVAL, CAREFULLY BACKFILL WITH NATIVE SOILS OVER TOP OF TANK. 8. FINAL GRADE THE SURFACE TO AVOID
- 8. FINAL GRADE THE SURFACE TO AVOID CHANNELLING SURFACE WATER TO TANK.
- 9. OUR DRIVER CANNOT ENTER ANY EXCAVATION.
- 10. ALL MEASUREMENTS ARE APPROXIMATE.
- 11. ALL TANK SEALS AND GASKETS SHALL MEET A.S.T.M. C1644 AS PER MANUFACTURER.

NOT TO SCALE

SHEET

S-10

REVISED 12/15/11

HITE BLOCK CO., INC
CONCRETE · PUMICE · BUILDING PRODUCTS
QUALITY MANUFACTURER SINCE 1947
WWW. WHITEBLOCKCOMPANY.COM

3219 East Trent Spokane, Washington 99212-1280 509/534-0651 FAX 509/534-0654

2,000 OR 2,500 GALLON SINGLE COMPARTMENT TANK