



INSTALLATION INSTRUCTIONS

- 1. EXCAVATE TANK HOLE WITH VERTICAL WALLS TO 1 FOOT LARGER THAN TANK ON ALL SIDES.
- IF BOTTOM OF HOLE IS STONY, INSTALL 3" OF COMPACT SAND & LEVEL OUT WITH SCREED.
- 3. INSTALL TANK IN CENTER OF HOLE, KEEPING 1 FOOT VOID SPACE ON ALL SIDES
- 4. AS TANK IS FILLING WITH WATER, FILL IN VOID SPACE WITH COMPACT GRANULAR (SANDY) SOIL FREE OF LARGE CLUMPS OF CLAY. TANK MUST BE BACKFILLED BEFORE USE.
- 5. INSTALL REST OF SYSTEM, & AFFIX RISERS TO TANK /ADAPTORS WITH WATERPROOF ADHESIVE.

- 6. PERFORM WATERTIGHTNESS TEST IN FIELD AS REQUIRED BY LOCAL JURISDICTION.
- UPON APPROVAL TO BACKFILL, CAREFULLY BACKFILL WITH NATIVE SOILS OVER TOP OF TANK.
- 8. FINAL GRADE THE SURFACE TO AVOID CHANNELLING SURFACE WATER TO TANK.
- 9. OUR DRIVER CANNOT ENTER ANY EXCAVATION.
- 10. ALL MEASUREMENTS ARE APPROXIMATE.
- 11. ALL TANK SEALS AND GASKETS SHALL MEET A.S.T.M. C1644 AS PER MANUFACTURER.

NOT TO SCALE

SHEET

<u>V-9</u>

2,000 AND 2,500 GALLON OIL / WATER SEPARATOR

HITE BLOCK CO., INC.

CONCRETE PUMICE BUILDING PRODUCTS
QUALITY MANUFACTURER SINCE 1947

WWW.WHITEBLOCKCOMPANY.COM

B219 East Trent Spokane, Washington 99212-1280 509/534-0651 FAX 509/534-0654

REVISED 12/07/11